

Installation Guide

Signs with no pre-drilled holes

Step 1



Place sign on wall. Ensure sign is level and gently mark out corners of the sign on the wall with a pencil.

Step 2



Place strips of high bond strength exterior grade double sided tape to the back of the sign. (Tape can be purchased from hardware outlets such as Bunnings or Masters. The appropriate amount of tape must be used to secure the sign.

Step 3



Place some liquid nails (Selleys Platinium liquid nails for metals) on the back of sign. Bond strenght may be comprimised if inappropriate products are used when sign is heated under direct sun.

Step 4



Place sign on wall over previously marked location. Apply firm and even pressure on sign especially over where double sided tape has been applied. The double sided tape is meant to hold up the sign temporarily while the liquid nails sets.

Step 5 (Optional)



For larger or heavier signs, proping of the sign may be required while the liquid nails sets. Timber can be wedged under the sign and on the sign to prop and hold the sign in place while the liquid nails cures. Please note that installation instructions provided on this page serve as a guide only. Sassysigns recommends installation by professionals. Appropriate saftey measures and equipment should be used during installation. Sassysigns is not responsile for any personal injuries or damages to the product arising from installation. Illuminated signs must be installed by a qualified electrician.

www.sassysigns.com.au

Installation Tips

1. Please note that this method of installation is only effective on flat rendered brick or timber walls. The recommended installation method cannot be used to install signs on walls having uneven wall surfaces i.e. stacked stone, pebble rock walls.

2. For weatherboard surfaces, place sign flat, spanning over two (top and bottom) weatherboards. Exterior grade strong double sided tape and liquid nails should be applied across where the sign comes in contact with the weatherboard surface.

3. When applying liquid nails to the back of the signs, take note not to put too much liquid nails near the edges or corners (apply liquid nails no closer than 15mm to the edges) or excess adhesive will squeeze out when the sign is pressed against the wall.

4. Excess liquid nails can be cleaned off using a soft cloth and turps.

5. Preparation of site prior to installation is essential. Lay a few thick towels below where the sign is going to sit so that it reduces the chance of damege should the sign unexpectedly fall during installation or prior to the liquid nails fully curing.